


EXTOL®

Extol Premium 8796901
160A Inverter Welder



CE

User's manual



CONTENT

§1 SAFETY	1
§1.1 SIGNAL EXPLANATION	1
§1.2 ARC WELDING DAMAGE	1
§1.3 THE KNOWLEDGE OF ELECTRIC AND MAGNETIC FIELDS	5
§2 SUMMARY	6
§ 2.1 BRIEF INTRODUCTION	6
§2.2 MODULE EXPLANATION	7
§2.3 WORKING PRINCIPLE	7
§2.4 VOLT-AMPERE CHARACTERISTIC	9
§3 INSTALLATION AND ADJUSTMENT	10
§3.1 PARAMETERS	10
§3.2 DUTY CYCLE & OVER HEAT	13
§3.3 MOVEMENT AND PLACEMENT	13
§3.4 POWER SUPPLY INPUT CONNECTION	14
§3.5 POLARITY CONNECTION (MMA)	14
§3.6 ASSEMBLING THE EQUIPMENT (TIG)	15
§4 OPERATION	16
§4.1 LAYOUT FOR THE PANEL	16
§4.2 CONTROL PANEL	17
§4.3 GUN SWITCH CONTROL CURRENT	23
§4.4 ARGON ARC WELDING OPERATION	24
§4.4.1 TIG welding (4T operation)	24
§4.4.2 TIG welding (2T operation)	25
§4.5 WELDING PARAMETERS	27
§4.5.1 Joint forms in TIG/MMA	27
§4.5.2 The explanation of welding quality	27
§4.5.3 TIG Parameters Matching	27
§4.6 OPERATION ENVIRONMENT	29
§4.7 OPERATION NOTICES	30
§5 MAINTENANCE & TROUBLESHOOTING	31
§5.1 MAINTENANCE	31
§5.2 TROUBLESHOOTING	32
§5.3 ELECTRICAL PRINCIPLE DRAWING	35

IMPORTANT: Read this Owner's Manual Completely before attempting to use this equipment. Save this manual and keep it handy for quick reference. Pay particular attention to the safety instructions we have provided for your protection. Contact your distributor if you do not fully understand this manual.

§1 SAFETY

§1.1 Signal Explanation



• The above signals mean warning! Notice! Running parts and getting an electric shock or thermal parts will take damage for your body or others. The corresponding notices are as follows. It is quite a safe operation after taking several necessary protection measures.

§1.2 Arc Welding Damage

- The following signals and word explanations are to some damages for your body or others happening on the welding operation. While seeing these, please remind of yourself or others to be dangerous.
- Only ones who are trained professionally can install, debug, operate, maintain and repair the equipment.
- During the operation, non-concerned people should be lift, especially for children.
- After shut off the machine power, please maintain and examine the equipment according to §5 because of the DC voltage existing in the electrolytic capacitors.



ELECTRIC SHOCK CAN KILL.

- Never touch electrical parts.
- Wear dry, hole-free gloves and clothes to insulate yourself.
- Insulate yourself from work and ground using dry insulation. Make certain the insulation is large enough to cover your full area of physical contact with work and ground.
- Take carefully when using the equipment in small place, falling-off and wet circumstance.
- Never close the machine power before installation and adjustment.
- Ensure to install the equipment correctly and ground the work or metal to be welded to a good electrical (earth) ground according to the operation manual.
- The electrode and work (or ground) circuits are electrically "hot" when the welder is on. Do not touch these "hot" parts with your bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.
- In semiautomatic or automatic wire welding, the electrode, electrode reel, welding head, nozzle or

semiautomatic welding gun are also electrically “hot”.

- Always be sure the work cable makes a good electrical connection with the metal being welded. The connection should be as close as possible to the area being welded.
- Maintain the electrode holder, work clamp, welding cable and welding machine in good, safe operating condition. Replace damaged insulation.
- Never dip the electrode in water for cooling.
- Never simultaneously touch electrically “hot” parts of electrode holders connected to two welders because voltage between the two can be the total of the open circuit voltage of both welders.
- When working above floor level, use a safety belt to protect yourself from a fall should you get a shock.



FUMES AND GASES CAN BE DANGEROUS.

- Welding may produce fumes and gases hazardous to health. Avoid breathing these fumes and gases. When welding, keep your head out of the fume. Use enough ventilation and/or exhaust at the arc to keep fumes and gases away from the breathing zone. When welding with electrodes which require special ventilation such as stainless or hard facing or on lead or cadmium plated steel and other metals or coatings which produce highly toxic fumes, keep exposure as low as possible and below Threshold Limit Values using local exhaust or mechanical ventilation. In confined spaces or in some circumstances, outdoors, a respirator may be required. Additional precautions are also required when welding on galvanized steel.
- Do not weld in locations near chlorinated hydrocarbon vapors coming from degreasing, cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas, and other irritating products.
- Shielding gases used for arc welding can displace air and cause injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.
- Read and understand the manufacturer’s instructions for this equipment and the consumables to be used, including the material safety data sheet and follow your employer’s safety practices.



ARC RAYS CAN BURN.

- Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the

arc when welding or observing open arc welding.

- Use suitable clothing made from durable flame-resistant material to protect your skin and that of your helpers from the arc rays.
- Protect other nearby personnel with suitable, non-flammable screening and /or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or metal.



SELF-PROTECTION

- Keep all equipment safety guards, covers and devices in position and in good repair. Keep hands, hair, clothing and tools away from V-belts, gears, fans and all other moving parts when starting, operating or repairing equipment.
- Do not put your hands near the engine fan. Do not attempt to override the governor or idler by pushing on the throttle control rods while the engine is running.



DO NOT add the fuel near an open flame welding arc or when the engine is running. Stop the engine and allow it to cool before refueling to prevent spilled fuel from vaporizing on contact with hot engine parts and igniting. Do not spill fuel when filling tank. If fuel is spilled, wipe it up and do not start engine until fumes have been eliminated.



WELDING SPARKS can cause fire or explosion.

- Remove fire hazards from the welding area. If this is not possible, cover them to prevent the welding sparks from starting a fire. Remember that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas. Avoid welding near hydraulic lines. Have a fire extinguisher readily available.
- Where compressed gases are to be used at the job site, special precautions should be used to prevent hazardous situation.
- When not welding, make certain no part of the electrode circuit is touching the work or ground. Accidental contact can cause overheating and create a fire hazard.
- Do not heat, cut or weld tanks, drums or containers until the proper steps have been taken to insure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause

an explosion even though they have been “cleaned”.

- Vent hollow castings or containers before heating, cutting or welding. They may explode.
- Sparks and spatter are thrown from the welding arc. Wear oil free protective garments such as leather gloves, heavy shirt, cuff less trousers, high shoes and a cap over your hair. Wear ear plugs when welding out of position or in confined places. Always wear safety glasses with side shields when in a welding area.
- Connect the work cable to the work as close to the welding area as practical. Work cables connected to the building framework or other locations away from the welding area increase the possibility of the welding current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.



Rotating parts may be dangerous.

- Use only compressed gas cylinders containing the correct shielding gas for the process used and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition.
- Always keep cylinders in an upright position securely chained to an undercarriage or fixed support.
- Cylinders should be located:
 - Away from areas where they may be struck or subjected to physical damage.
 - A safe distance from arc welding or cutting operations and any other source of heat, sparks, or flame.
- Never allow the electrode, electrode holder or any other electrically “hot” parts to touch a cylinder.
- Keep your head and face away from the cylinder valve outlet when opening the cylinder valve.
- Valve protection caps should always be in place and hand tight except when the cylinder is in use or connected for use.

§1.3 The knowledge of Electric and Magnetic Fields

Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). The discuss on the effect of EMF is ongoing all the world. Up to now, no material evidences show that EMF may have effects on health. However, the research on damage of EMF is still ongoing. Before any conclusion, we should minimize exposure to EMF as few as possible.

In order to minimize EMF, we should use the following procedures:

- Route the electrode and work cables together – Secure them with tape when possible.
- All cables should be put away and far from the operator.
- Never coil the power cable around your body.
- Make sure welding machine and power cable to be far away from the operator as far as possible according to the actual circumstance.
- Connect the work cable to the workpiece as close as possible to the area being welded.
- The people with heart-pacemaker should be away from the welding area.

§2 SUMMARY

§ 2.1 Brief Introduction

Magic Tig160P/ 200P/200P DV welding machine adopts the latest pulse width modulation (PWM) technology and insulated gate bipolar transistor (IGBT) power module, which can change work frequency to medium frequency so as to replace the traditional hulking work frequency transformer with the cabinet medium frequency transformer. Thus, it is characterized with portable, small size, light weight, low consumption and etc.

The parameters of Magic Tig 160P/200P/200P DV on the front panel all can be adjusted continuously and steplessly, such as start current, crater arc current, welding current, base current, duty ratio, upslope time, downslope time, pre-gas, post-gas, pulse frequency, hot start and arc force etc. When welding, it takes high frequency and high voltage for arc igniting to ensure the success ratio of igniting arc.

Magic Tig 160P/200P/200P DV Characteristics:

- ★ Magic Tig 200P DV Dual voltage:110-127V/220-240V.
- ★ The ZVS soft switch technology reduces the IGBT switching loss.
- ★ DC Pulsed TIG and MMA, adopt IGBT and advanced PWM technology
- ★ High performance MCU, Digital control, Digital display
- ★ Preset all parameters with hold process
- ★ HF/Lift TIG, current down slope and up slope, gas post-flow, Pulse Frequency
- ★ Intelligent protection: over-voltage, under-voltage, over-current, over-heat
- ★ Reduce the weight of the machine , improve the mobility of the welder.

1.For MMA, polarity connection can be chosen according to different electrodes , please refer to §3.5;

2.For DC TIG, DCEP is used normally (workpiece connected to positive polarity, while torch connected to negative polarity). This connection has many characters, such as stable welding arc, low tungsten pole loss, more welding current, narrow and deep weld;

3.DC Pulsed TIG has the following characters: 1) Pulse heating. Metal in Molten pool has short

time on high temperature status and freezes quickly, which can reduce the possibility to produce hot crack of the materials with thermal sensitivity. 2) The workpiece gets little heat. Arc energy is focused. Be suitable for thin sheet and super thin sheet welding. 3) Exactly control heat input and the size of the molten pool. The depth of penetration is even. Be suitable for welding by one side and forming by two sides and all position welding for pipe. 4) High frequency arc can make metal for microlite fabric, eliminate blowhole and improve the mechanical performance of the joint. 5) High frequency arc is suitable for high welding speed to improve the productivity.

MAGIC TIG 160P/200P/200P DV is suitable for all positions welding for various plates made of stainless steel, carbon steel, alloyed steel, titanium, magnesium, cuprum, etc, which is also applied to pipe installment, mould mend, petrochemical, architecture decoration, car repair, bicycle, handicraft and common manufacture.


MMA——Manual Metal Arc welding

PWM——Pulse-Width Modulation

IGBT——Insulation Gate Bipolar Transistor

TIG——Tungsten Insert Gas welding


§2.2 Module Explanation




§2.3 Working Principle

The working principle of MAGIC TIG 160P/200P/200P DV is shown as the following figure. single phase work frequency AC 110V/220V (50 Hz) is rectified into DC (about 310V), then is converted to medium frequency AC (about 40KHz) by inverter device (IGBT), after reducing voltage by medium transformer (the main transformer) and rectifying by medium frequency rectifier (fast recovery diode), and is outputted by inductance filtering. The circuit adopts current feedback control

technology to insure current output stably. Meanwhile, the welding current parameter can be adjusted continuously and steplessly to meet with the requirements of welding craft.



MAGIC TIG-200P DV




MAGIC TIG-160P/200P

§2.4 Volt-Ampere Characteristic

MAGIC TIG 160P/200P/200P DV welding machine has an excellent volt-ampere characteristic, whose graph is shown as the following figure. The relation between the conventional rated loading voltage U_2 and the conventional welding current I_2 is as follows:

When $I_2 \leq 600A$, $U_2 = 10 + 0.04I_2(V)$; When $I_2 > 600A$, $U_2 = 34(V)$.



§3 Installation and Adjustment

§3.1 Parameters

Model	MAGIC TIG -200P DV			
Power supply voltage(V)	1~110±10%		1~220±10%	
Frequency(Hz)	50/60			
	MMA	TIG	MMA	TIG
Rated Input Power(KW)	3.7	3.3	6.4	4.3
Rated Input Current(A)	50	45	40.5	27.3
Duty Cycle(40℃ 10min)	35% 125A	40% 160A	35% 200A	
	60% 95A	60% 135A	60% 170A	
	100% 80A	100% 105A	100% 120A	
No Load Voltage(V)	25V(60)			
Welding Current Range(A)	5~125	5~160	5~200	
Pulse Frequency(Hz)	0.5~100			
Pulse Width Range(%)	5~100			
Up Slope Time(S)	0~5			
Down Slope Time(S)	0~5			
Pre Flow(S)	0~1			
Post Flow(S)	3~10			
Efficiency(%)	84%			
Power factor	0.68		0.7	
Net Weight(Kg)	7.5			
Dimensions(mm)	400*120*240			
Protection Class	IP23			
Insulation Class	F			
Cooling	AF			

Note: The above parameters are subject to change with the improvement of machines.

Model	MAGIC TIG-200P	
Power supply voltage(V)	1~220±10%	
Frequency(Hz)	50/60	
	MMA	TIG
Rated Input Power(KW)	5.3	4.2
Rated Input Current(A)	36.6	28.6
Duty Cycle(40℃ 10min)	30% 170A	25% 200A
	60% 120A	60% 120A
	100% 100A	100% 100A
No Load Voltage(V)	25V(60)	
Welding Current Range(A)	5~170	5~200
Pulse Frequency(Hz)	0.5~100	
Pulse Width Range(%)	5~100	
Up Slope Time(S)	0~5	
Down Slope Time(S)	0~5	
Pre Flow(S)	0~1	
Post Flow(S)	0.1~10	
Efficiency (%)	86%	83%
Power factor	0.64	
Net Weight(Kg)	6.7	
Dimensions(mm)	385*120*240	
Protection Class	IP23	
Insulation Class	F	
Cooling	AF	

Note: The above parameters are subject to change with the improvement of machines.


Model	MAGIC TIG-160P	
Power supply voltage(V)	1~240±10%	
Frequency(Hz)	50/60	
	MMA	TIG
Rated Input Power(KW)	4.8	3.2
Rated Input Current(A)	31.6	20.8
Duty Cycle(40℃ 10min)	20% 160A 60% 100A 100% 80A	25% 160A 60% 100A 100% 80A
No Load Voltage(V)	25V(60)	
Welding Current Range(A)	5~160	
Pulse Frequency(Hz)	0.5~100	
Pulse Width Range(%)	5~100	
Up Slope Time(S)	0~5	
Down Slope Time(S)	0~5	
Pre Flow(S)	0~1	
Post Flow(S)	0.1~10	
Efficiency (%)	88%	83%
Power factor	0.64	
Net Weight(Kg)	6.7	
Dimensions(mm)	385*120*240	
Protection Class	IP23	
Insulation Class	F	
Cooling	AF	

Note: The above parameters are subject to change with the improvement of machines.

§3.2 Duty cycle & Over heat

The letter “X” stands for duty cycle, which is defined as the proportion of the time that a machine can work continuously within a certain time (10 minutes). The rated duty cycle means the proportion of the time that a machine can work continuously within 10 minutes when it outputs the rated welding current.

The relation between the duty cycle “X” and the output welding current “I” is shown as the right figure.



If the welder is over-heat, the IGBT over-heat protection unit inside it will output an instruction to cut output welding current, and brighten the over-heat pilot lamp on the front panel. At this time, the machine should be relaxed for 15 minutes to cool the fan. When operating the machine again, the welding output current or the duty cycle should be reduced.

§3.3 Movement and placement

Please take care for the welder when moving it, and do not make it sloped.

It also can be moved by the handle on the top of the welder. Place the welder well when moving it to the right position. When the machine gets to the destination, it needs to be fixed up to avoid gliding.

When using forklift, its arm length must be long enough to reach the outside so as to ensure lifting safely.

The movement may result in the potential danger or substantive hazard, so please make sure that the machine is on the safe position before using it.

§3.4 Power supply input connection

MAGIC TIG 200P DV welding machines' power supply connects to 110V/220V.

MAGIC TIG 160P/200P welding machines' power supply connects to 220V.

When the power supply voltage is over the safe work voltage, there are over voltage and under voltage protection inside the welder, the alarm light will on, at the same time, the current output will be cut off.

If the power supply voltage continually goes beyond the safe work voltage range, it will shorten the welder life-span. The below measures can be used:


- Change the power supply input net. Such as, connect the welder with the stable power supply voltage of distributor;
- Induce the machines using power supply in the same time;
- Set the voltage stabilization device in the front of power cable input.

§3.5 Polarity Connection (MMA)


(take MAGIC TIG-200P DV for an example)

MMA (DC): Choosing the connection of DCEN or DCEP according to the different electrodes.

Please refer to the electrode manual..



§3.6 Assembling the equipment (TIG)




(take MAGIC TIG-200P DV for an example)

- Workpiece is connected to the positive electrode of welding machine, and welding torch is connected to the negative electrode, which is called DC POSITIVE CONNECTION; otherwise, that is called DC NEGATIVE CONNECTION. Generally, it is usually operated in DC POSITIVE CONNECTION in TIG welding mode.
- The control cable of torch switch consists of 2 wires, UP-DOWN control of 3 wires and the aero socket has 8 leads.
- Consumable parts for TIG torch, such as tungsten electrode、tip、gas nozzle、electrode shield(short/long) , please enquire us by mail or phone according to the accessory codes.
- When MAGIC TIG-series welding machines are operated in HF ignition method, the ignition spark can cause interferences in equipment near the welding machine. Be sure to take specially safety precautions or shielding measures.


§4 Operation

§4.1 Layout for the panel



- 1 **Shield gas connector** Is connected to the gas input pipe of torch.
- 2 **Negative output** The welder's negative polarity output.
- 3 **Aero socket** Is connected to torch switch control wire. (the Aero socket has 8 leads, lead 2 - lead 3 are connected to torch switch control wire, lead 5 - lead 6- lead 7 are connected to adjust current button) .
- 4 **Positive output** The welder's positive polarity output.
- 5 **Power source switch** Switch to "ON", the welder is turned on, while switch to "OFF", the welder is turned off.
- 6 **Shield gas input joint** To connect one head of the gas hose while the other head of which is connected to argon gas cylinder.
- 7 **Power source input** To connect power source.
- 8 **Fan** When the electric welding machine is over-heat, the fan operates. It is used for cooling the components and parts inside the welder.

§4.2 Control panel



I 、 Introduction the pilot light of MAGIC TIG-200P/200P DV operation panel:

- 1.——Pre Flow Time (L1)
- 2.——Start Current (L2)
- 3.——Up Slope Time (L3)
- 4.——Welding Current (Peak Current) (L4)
- 5.——Base Current (L5)
- 6.——Pulse Frequency (L6)
- 7.——Pulse Width (L7)
- 8.——Down Slope Time (L8)
- 9.——Crater Current (L9)
- 10.——Post Flow Time (L10)
- 11.——Pulse Selection light (L11)
- 12.——Hot Start (L12)
- 13.——Arc Force (L13)
- 14.——Alarm Pilot Light (L14)
- 15.——Power Pilot Light (L15)

II 、 The function of 'welding mode selection switch':

1. GAS——Gas test function; In GAS shelf, the gas is given all the time untill the welding is stopped.
2. 4T_LIFT——TIG Lifting arc, long welding function.
3. 2T_LIFT——TIG Lifting arc, short welding function.
4. 4T_HF——TIG HF striking arc, long welding function.
5. 2T_HF——TIG HF striking arc, short welding function.
6. MMA——MMA function.

III. Operations:


1. MMA parameters adjustment

Adjust the 'welding mode selection switch' to MMA function. In MMA mode, only three parameters (welding current, hot start, arc force) can be adjusted.


MMA parameters adjustment: Turn on the welder, the welding current can be adjusted directly; If adjust the selection knob, the welding current LED (L4) is twinkling; It means the welding current can be adjusted. If the adjustment is completed, confirm the parameter by pressing the 'selection knob' or the system will confirm the parameter automatically after 3 seconds.

Other parameters such as arc force adjustment: press the 'selection knob'; Adjust the 'selection knob' and select the arc force LED(L13 is on); Press the 'selection knob' again, the arc force LED(L13) is twinkling; It means the arc force can be adjusted. If the adjustment is completed, press the 'selection knob' and confirm the parameter; Or the system will confirm the parameter automatically after 3 seconds. Operation flow as follows:


Step one: 'Welding mode selection switch' selects MMA mode, press the 'selection knob';



Step two: Adjust the 'selection knob' and select the arc force LED(L13 is on); Press the 'selection knob' again, the arc force LED(L13) is twinkling; It means the arc force can be adjusted.



Step three: If the adjustment is completed, press the 'selection knob' and confirm the parameter; Or the system will confirm the parameter automatically after 3 seconds.




2. TIG parameters adjustment

Adjust 'welding mode selection switch' to TIG mode. If in TIG 4T mode and the output pulse function is turned on, all parameters (L1~L11) of TIG can be adjusted. If in TIG 2T mode and the output pulse function is turned on, the start current and crater current is 5A; If the pulse function is closed, the parameter of base current(L5), pulse frequency(L6) and pulse width(L7) cannot be adjusted.

TIG parameters adjustment: The welding current (L4) can be adjusted directly when the welder is tune on. Adjust the 'selection knob', the welding current LED (L4) is twinkling; It means the welding current can be adjusted. If the adjustment is completed, confirm the parameter by pressing the 'selection knob' or the system will confirm the parameter automatically after 3 seconds.


Other parameters adjustment: Take 'pre flow time' for an example. Press the 'selection knob'; Adjust the 'selection knob' and select the pre flow time LED (L1 is on); Press the 'selection knob' again, the pre flow time LED (L1) is twinkling; It means the pre flow time can be adjusted. If the adjustment is completed, confirm the parameter by pressing the 'selection knob'; or the system will confirm the parameter automatically after 3 seconds. Operation flow as follows:

Step one: 'Welding mode selection switch' select TIG 4T or 2T. Press the 'selection knob';




Step two: Adjust the 'selection knob' and select the pre flow time LED (L1 is on); Press the 'selection knob' again, the pre flow time LED (L1) is twinkling; It means the pre flow time can be adjusted.

Adjust the 'selection knob' and select the pre flow time LED (L1 is on); Press the 'selection knob' again, the pre flow time LED (L1) is twinkling; It means the pre flow time can be adjusted




Step three: If the adjustment is completed, confirm the parameter by pressing the 'selection knob'; or the system will confirm the parameter automatically after 3 seconds.

If the adjustment is complete, confirm the parameter by pressing the 'selection knob'; or the system will confirm the parameter automatically after 3 seconds



Output pulse selection: Press the 'selection knob'. Adjust the 'selection knob' and select the pulse LED (L11 is on); press the 'selection knob' again, the pulse LED (L11) is twinkling; It means the output pulse function can be turned on or turned off. If the display is "ON", the output pulse function is turned on; if the display is "OFF", the output pulse function is turned off. When the pulse LED (L11) is twinkling, press the 'selection knob' again, the output pulsed conditions transform by "ON" into "OFF" or transform by "OFF" into "ON". Operation flow as follows:


Step one: 'Welding mode selection switch' select TIG 4T or 2T. Press the 'selection knob';



Step two: Adjust the 'selection knob' and select the output pulse LED (L11 is on); press the 'selection knob' again, the pulse LED (L11) is twinkling; It means the output pulse function can


be turned on or turned off.

Adjust the 'selection knob' and select the pulse LED (L11 is on); Press the 'selection knob' again, the pulse LED (L11) is twinkling; It means the output pulse function can be turned on or turned off.




Step three: Press the 'selection knob' again, the output pulsed conditions transform by "ON" into "OFF" or transform by "OFF" into "ON".

Press the 'selection knob' again, the output pulse function is turned off.



Complete the adjustment after 3 seconds, the operation panel will return to original condition; welding current LED (L4) is on. If the welding mode is TIG and the output pulse function is turned on, the pulse pilot light (L11) is on. If the output pulse function is turned off, the pulse pilot light (L11) is off. In MMA mode, the pulse pilot light (L11) is off. All preset parameters with hold function.

If the parameter indicator lights up, then the selected parameter can be altered on adjusting dial.



Available parameters where 2T and 4T mode have been selected:

Tpr Gas pre-flow time

Unit S
Setting range 0.1—1
Factory setting

Is Starting current (only with 4T)

Unit A
Setting range 5—100% of main current Iw
Factory setting

Tup Upslope time

Unit S
Setting range 0—5
Factory setting

Iw Welding current

Unit A
Setting range 5—200;

Ib Base current

Unit A
Setting range 5—200;

Important! Only selectable when “pulse key” has been pressed.

Dcy Ratio of pulse duration to base current duration

Unit %
Setting range 5—100
Factory setting

Important! Only selectable when “pulse key” has been pressed.

Fp Pulse frequency

Unit Hz
Setting range 0.5—100
Factory setting

Important! Only selectable when “pulse key” has been pressed.

Tdown Downslope time

Unit S
Setting range 0—5
Factory setting


Ic Crater arc current (only with 4T)

Unit S
Setting range 5—100% of main current Iw ;
Factory setting

Tpo Gas post-flow time

Unit S
Setting range 0.1—10
Factory setting

§4.3 Gun switch control current




§4.4 Argon Arc Welding Operation

§4.4.1 TIG welding (4T operation)

The start current and crater current can be pre-set. This function can compensate the possible crater that appears at the beginning and end of the welding. Thus, 4T is suitable for the welding of medium thickness plates.

Pulsed TIG long welding (4T):




Introduction:

- 0: Press and hold the gun switch, Electromagnetic gas valve is turned on. The shielding gas starts to flow;
 - 0~t1: Pre flow time, adjustment range of pre flow time :0.1~1.0S;
 - t1: Striking success, adjustment range of start current: 5~200A;
 - t2: Loosen the gun switch, the output current slopes up from start current; if the output pulse function is turned on, the output current is pulsed;
 - t2~t3: Output current slopes up to the setting current value; adjustment range of up slope time 0~10.0S ;
 - t3~t4: Welding process. During this period, the gun switch is loosen;
- Note: If the output pulse function is turned on, the output current is pulsed. If the output pulse function is turned off, the output current is DC current;
- t4: Repress down the gun switch, the output current slopes down to crater current; if the output pulse function is turned on, the slope down current is pulsed;
 - t4~t5: Down slope time, adjustment rang of down slope time: 0~10.0S;
 - t5~t6: Crater current holds time; adjustment range of crater current: 5~200A ;

- t6: Loosen the gun switch, stop arc, and keep on argon flowing;
- t6~t7: Post flow time, adjustment range of post flow time: 0.1~10.0S;
- t7: Electromagnetic valve is closed and stop argon flowing. Welding is finished.

§4.4.2 TIG welding (2T operation)

Pulsed TIG short welding (2T):



Introduction:

- 0: Press and hold the gun switch, Electromagnetic gas valve is turned on. The shielding gas starts to flow;
 - 0~t1: Pre flow time, adjustment range of pre flow time :0.1~1.0S;
 - t1~t2: Striking success, the output current slopes up to the setting current from minimum current (5A); if the output pulse function is turned on, the slope up current is pulsed;
 - t2~t3: During the whole welding process, the gun switch is pressed and held without releasing;
- Note: If the output pulse function is turned on, the output current is pulsed. If the output pulse function is turned off, the output current is DC current;
- t3: Loosen the gun switch, the output current slopes down; if the output pulse function is turned on, the slope down current is pulsed;
 - t3~t4: The output current slopes down to minimum current (5A), stop arc; adjustment range of down slope time: 0~5S;
 - t4~t5: Post flow time, adjustment range of post flow time: 0.1~10.0S;
 - t5: Electromagnetic valve is closed and stop argon flowing. Welding is finished.

Short circuit protect function:

- ① TIG /DC/LIFT: If the tungsten electrode touches the workpiece when welding, the current will drop to 30A, which can reduce the tungsten spoilage farthestly, prolong the using life of the tungsten electrode, and prevent tungsten clipping.
- ② TIG /DC/HF: If the tungsten electrode touches the workpiece when welding, the current will drop to 0 within 1s, which can reduce the tungsten spoilage farthestly, prolong the using life of the tungsten electrode, and prevent tungsten clipping.
- ③ MMA operation: if the electrode touches workpiece over two seconds, the welding current will drop to the 0 automatically to protect the electrode.


Prevent arc-break function: TIG operation, Avoid arc-break with special means, even if arc-break occurs the HF will keep the arc stable.

Notices:

- Check the condition of welding and connection units firstly, otherwise there will be malfunction such as ignition spark、gas leakage、out of control and so on.
- Check that whether there is enough Argon gas in the shield gas cylinder, you can test the electromagnetic gas valve through the switch on the front panel.
- Do not let the torch aim at your hand or else of your body. When you press the torch switch, the arc is ignited with a high-frequency, high-voltage spark, and the ignition spark can cause interferences in equipment.
- The flow rate is set according to the welding power used in the job. Turn the regulation screw to adjust the gas flow which is shown on the gas hose pressure meter or the gas bottle pressure meter.
- The spark ignition works better if you keep the 3mm distance from the workpiece to the tungsten electrode during the ignition.

§4.5 Welding Parameters

§4.5.1 Joint forms in TIG/MMA



§4.5.2 The explanation of welding quality

The relation of welding area color & protect effect of stainless steel

Welding area color	argent , golden	blue	red-grey	grey	black
Protect effect	best	better	good	bad	worst

The relation of welding area color & protect effect of Ti-alloy

Welding area color	bright argent	orange-yellow	blue-purple	caesious	white powder of titanium oxid
Protect effect	best	better	good	bad	worst

§4.5.3 TIG Parameters Matching

The corresponding relationship between gas nozzle diameter and electrode diameter

Gas nozzle diameter/mm	Electrode diameter/mm
6.4	0.5
8	1.0
9.5	1.6 or 2.4
11.1	3.2
Notice: the above parameters originate from 《Welding Dictionary》 P142, Volume 1 of Edition 2.	

Welding current range/A	DC positive connection	
	Gas nozzle diameter/mm	Gas flow rate/L • min ⁻¹
10~100	4~9.5	4~5
101~150	4~9.5	4~7
151~200	6~13	6~8
201~300	8~13	8~9

tungsten electrode diameter /mm	sharpened of the electrode diameter/mm	angle of cone (°)	background current/A
1.0	0.125	12	2~15
1.0	0.25	20	5~30
1.6	0.5	25	8~50
1.6	0.8	30	10~70
2.4	0.8	35	12~90
2.4	1.1	45	15~150
3.2	1.1	60	20~200

TIG of stainless steel (single run welding)

Workpiece thickness /mm	Joint form	tungsten electrode diameter/mm	welding wire diameter/mm	Argon gas flow rate/ L • min ⁻¹	welding current (DCEP)	Welding speed/ cm • min ⁻¹
0.8	Butt joint	1.0	1.6	5	20~50	66
1.0	Butt joint	1.6	1.6	5	50~80	56
1.5	Butt joint	1.6	1.6	7	65~105	30
1.5	Corner joint	1.6	1.6	7	75~125	25
2.4	Butt joint	1.6	2.4	7	85~125	30
2.4	Corner joint	1.6	2.4	7	95~135	25
3.2	Butt joint	1.6	2.4	7	100~135	30
3.2	Corner joint	1.6	2.4	7	115~145	25
4.8	Butt joint	2.4	3.2	8	150~225	25
4.8	Corner joint	3.2	3.2	9	175~250	20

Notice: the above parameters originate from 《Welding Dictionary》 P150, Volume 1 of Edition 2.

Parameters of piping back sealing welding for mild steel (DCEP)

Piping diameter Φ/mm	Tungsten electrode diameter/mm	Gas nozzle diameter/mm	Welding wire diameter/mm	Welding current/A	Arc voltage/V	Argon flow rate / L • min ⁻¹	Welding rate / cm • min ⁻¹
38	2.0	8	2	75~90	11~13	6~8	4~5
42	2.0	8	2	75~95	11~13	6~8	4~5
60	2.0	8	2	75~100	11~13	7~9	4~5
76	2.5	8~10	2.5	80~105	14~16	8~10	4~5
108	2.5	8~10	2.5	90~110	14~16	9~11	5~6
133	2.5	8~10	2.5	90~115	14~16	10~12	5~6
159	2.5	8~10	2.5	95~120	14~16	11~13	5~6
219	2.5	8~10	2.5	100~ 120	14~16	12~14	5~6
273	2.5	8~10	2.5	110~ 125	14~16	12~14	5~6
325	2.5	8~10	2.5	120~ 140	14~16	12~14	5~6

Notice: the above parameters originate from 《Welding Dictionary》 P167, Volume 1 of Edition 2.

§4.6 Operation Environment

- Height above sea level is below 1000m.
- Operation temperature range:-10°C~+40°C.
- Relative humidity is below 90 % (20°C), relative humidity is below 50 % (40°C).
- The inclination of the power source does not exceed 10°.
- Protect the machine against heavy rain or in hot circumstance against direct sunshine.
- The content of dust, acid, corrosive gas in the surrounding air or substance can not exceed normal standard.
- Take care that there is sufficient ventilation during welding. There is at least 30cm free distance between the machine and wall.

§4.7 Operation Notices

- Read §1 carefully before attempting to use this equipment.
- Connect the ground wire with the machine directly, and refer to §3.5.
- In case closing the power switch, no-load voltage may be exported. Do not touch the output electrode with any part of your body.
- Before operation, no concerned people should be left. Do not watch the arc in unprotected eyes.
- Ensure good ventilation of the machine to improve duty ratio.
- Turn off the engine when the operation finished to economize energy source.
- When power switch shuts off protectively because of failure. Don't restart it until problem is resolved. Otherwise, the range of problem will be extend

§5 Maintenance & Troubleshooting

§5.1 Maintenance

In order to guarantee that arc welding machine works high-efficiently and in safety, it must be maintained regularly. Let customers understand the maintenance methods and means of arc welding machine more , enable customers to carry on simple examination and safeguarding by oneself, try one's best to reduce the fault rate and repair times of arc welding machine, so as to lengthen service life of arc welding machine .Maintenance items in detail are in the following table.

- **Warning: For safety while maintaining the machine, please shut off the supply power and wait for 5 minutes, until capacity voltage already drop to safe voltage 36V!**

date	Maintenance item
Daily examination	Observe that whether panel knob and switch in the front and at the back of arc welding machine are flexible and put correctly in place. If the knob has not been put correctly in place, please correct; If you can't correct or fix the knob , please replace immediately; If the switch is not flexible or it can't be put correctly in place, please replace immediately; Please get in touch with maintenance service department if there are no accessories. After turn-on power, watch/listen to that whether the arc welding machine has shaking, whistle calling or peculiar smell. If there is one of the above problems, find out the reason to get rid of; if you can't find out the reason, Please contact local this area agent or the branch company. Observe that whether the display value of LED is intact. If the display number is not intact, please replace the damaged LED. If it still doesn't work, please maintain or replace the display PCB. Observe that whether the min/max value on LED accords with the set value. If there is any difference and it has affected the normal welding craft, please adjust it. Check up that Whether fan is damaged and is normal to rotate or control. If the fan is damaged, please change immediately. If the fan does not rotate after the arc welding machine is overheated , observe that whether there is something blocked in the blade, if it is blocked, please get rid of ; If the fan does not rotate after getting rid of the above problems, you can poke the blade by the rotation direction of fan. If the fan rotates normally, the start capacity should be replaced ; If not, change the fan. Observe that whether the fast connector is loose or overheated. if the arc welding machine has the above problems, it should be fastened or changed. Observe that Whether the current output cable is damaged. If it is damaged, it should be

	wrapped up, insulated or changed.
Monthly examination	Using the dry compressed air to clear the inside of arc welding machine. Especially for clearing up the dusts on radiator, main voltage transformer, inductance, IGBT module, the fast recover diode and PCB, etc. Check up the bolt in arc welding machine, if it is loose, please screw down it. If it is skid, please replace. If it is rusty, please erase rust on bolt to ensure it works well.
Quarter-yearly examination	Whether the actual current accords with the displaying value. If they does not accord, they should be regulated. The actual current value can be measured by the adjusted plier-type ampere meter.
Yearly examination	Measure the insulating impedance among the main circuit, PCB and case, if it below 1MΩ, insulation is thought to be damaged and need to change , and need to change or strengthen insulation.

§5.2 Troubleshooting

- Before arc welding machines are dispatched from the factory, they have already been debugged accurately. So forbid anyone who is not authorized by us to do any change to the equipment!
- Maintenance course must be operated carefully. If any wire becomes flexible or is misplaced, it maybe potential danger to user!
- Only professional maintenance personal who is authorized by us could overhaul the machine!
- Guarantee to shut off the arc welding machine's power before turn on the outline of the equipment!
- If there is any problem and has no the authorized professional maintenance personal, please contact local agent or the branch company!

If there are some simple troubles of TP-series welding machine, you can consult the following overhauling chart:


S/N	Troubles	Reasons	Solution
1	Turn on the power source, and fan works, but the power pilot lamp is not on.	The power light damaged or connection is not good	Check and repair Pr7

S/N	Troubles		Reasons	Solution
			The transformer of power is broken	Repair or change the transformer
			Control PCB failures	Repair or change the control Pr4
2	Turn on the power source, and the power lamp is on, but fan doesn't work		There is something in the fan	Clear out
			The start capacitor of fan damaged	Change capacitor
			The fan motor damaged	Change fan
3	Turn on the power source, the power lamp is not on, and fan doesn't work		No power supply input	Check whether there is power supply
			The fuse inside the machine damaged	Change it (10A)
4	The number on the display is not intact.		The LED in the display is broken	Change the LED
5	The max and min value displayed doesn't accord with the set value.		The max value is not accordant (refer to §3.1)	Adjust potentiometer Imin on the power board.
			The min value is not accordant (refer to §3.1)	Adjust potentiometer Imax in the current meter.
6	No no-load voltage output (MMA)		The machine is damaged	Check the main circuit and the Pr4.
7	Arc can not be ignited (TIG)	There is spark on the HF igniting board.	The welding cable is not connected with the two output of the welder.	Connect the welding cable to the welder's output.
			The welding cable damaged.	Repair or change it.
			The earth cable connected unstably.	Check the earth cable.
			The welding cable is too long.	Use an appropriate welding cable.
			There is oil or dust on the workpiece.	Check and remove it.
			The distance between tungsten electrode and workpiece is too long.	Reduce the distance (about 3mm).
		There is not spark on the HF igniting board.	The HF igniting board does not work.	Repair or change Pr8
			The distance between the discharger is too short.	Adjust this distance (about 0.7mm).
			The malfunction of the welding gun switch.	Check the welding gun switch, control cable and aero socket.
8	No gas flow (TIG)		Gas cylinder is close or gas pressure is low	Open or change the gas cylinder
			Something in the valve	Remove it
			Electromagnetic valve is damaged	Change it
9	Gas always flows		The gas-test on the front panel is on	The gas-test on the front panel is off
			Something in the valve	Remove it
			Electromagnetic valve is damaged	Change it
			The adjustment knob of pre-gas time on the front panel is damaged	Repair or change it

S/N	Troubles	Reasons		Solution
10	The welding current can not be adjusted	The welding current potentiometer on the front panel connection is not good or damaged		Repair or change the potentiometer
12	The welding current displayed isn't accordant with the actual value.	The min value displayed isn't accordant with the actual value. (Please refer to § 3.1)		Adjust potentiometer Imin on the power board.
		The max value displayed isn't accordant with the actual value. (Please refer to § 3.1)		Adjust potentiometer Imax on the power board.
13	The penetration of molten pool is not enough.	The welding current is adjusted too low		Increase the welding current
		The arc is too long in the welding process		Use 2T operation
14	The alarm lamp on the front panel is on	Over heat protection	Working time too long	Reduce the duty cycle (work intermittently)
		Over-voltage protection	Power supply fluctuates	Using the stable power supply
		Low-voltage protection	Power supply fluctuates	Using the stable power supply
			Too many machines using power supply in the same time	Reduce the machines using power supply in the same time
		Over-current protection	Unusual current in the main circuit	Check and repair the main circuit and drive Pr6

§5.3 Electrical principle drawing

MAGIC TIG-200P DV system chart



MAGIC TIG-160P/200P system chart

